



## Surface Mount Hook Installation

Stainless hooks with adhesive backing adhere best to smooth, non-porous surfaces such as wood, glass, or metal. To ensure a firm bond, surfaces should be totally free of dirt and soap film before attaching the hook.

**Two surface mount hooks are required to obtain adequate bond.**

1. Mark the center point where you want the caddy to be placed on the door.
2. Measure the distance between the grommets on each end of the caddy (far left and far right) and divide that total by two and make two more marks to the right and left of the center point.
3. Clean the surface area - **VERY IMPORTANT!**
  - a. Porous surfaces - scrub with a non-abrasive household cleaner, rinse, dry thoroughly.
  - b. **Clean the mounting surface with 91% or 99% rubbing alcohol and dry thoroughly with a clean cloth. This is a very important step!**
4. Application - **VERY IMPORTANT!**
  - a. Remove the backing from the tape on the back of the hook.
  - b. Firm application pressure develops better adhesive contact. Improves bond strength.
  - c. We strongly recommend that you use a rubber roller (pictured above) so that good surface contact can be attained.
  - d. Use a small hand-held level to ensure that the hooks are installed straight.
5. **Time requirement.** 3M recommends that you allow 24 hours for the adhesive/hook to set. It is recommended that you do not hang the caddy on the hook until the adhesive is set.

## Surface Mount Hook – Removal

1. Using a hair dryer, heat the length of the hook for 15-30 seconds to break the bond between the adhesive and the surface.
2. Simply twist the hook, left to right, and it will remove cleanly from the surface.
3. Clean the area with 91% or 99% alcohol to remove any residue.